
Meridian 1

Trunk cards

Description

Document Number: 553-3001-106

Document Release: Standard 5.00

Date: October 1997

© 1994, 1997

All rights reserved

Printed in the United States of America

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules, and the radio interference regulations of Industry Canada. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

SL-1 and Meridian 1 are trademarks of Northern Telecom.

Revision history

December 1994

Standard, release 1.0. This is the initial release of this document. It supercedes:

- *QPC71 E&M/DX Signaling and Paging Trunk Card description* (553-2001-187)
- *Recorded Telephone Dictation Trunk Cards description* (553-2001-188)
- *QPC237 4-Wire E&M/DX Trunk Card description* (553-2001-190)
- *CO/FX/WATS Trunk Cards description* (553-2201-185)
- *QPC449 Loop Signaling Trunk Cards description* (553-2201-186)
- *QPC74 Recorded Announcement Trunk Card description* (553-2201-194)
- *NT8D14 Universal Trunk Card description* (553-3001-171)
- *NT8D15 E&M Trunk Card description* (553-3001-172)

July 1995

Standard, release 2.00. This document is reissued to incorporate technical corrections and indexing. Changes are noted by revision bars in the margins.

August 1996

Standard, release 3.00. Changes are noted by revision bars in the margins.

August 1996

Standard, release 4.00. Changes are noted by revision bars in the margins.

October 1997

Standard, release 5.00. This document is reissued to include information on the NT8D14BB (Release 10 and later), which provides identical functionality as the NT8D14 Universal Trunk card, but which has only three jumpers instead of the four present on previous versions of this card.

Contents

About this document	1
References	1
Description	3
Overview	3
Meridian 1 architecture	4
Selecting a trunk card	7
Intelligent peripheral equipment (IPE) trunk cards	7
Peripheral equipment (PE) trunk cards	9
Installation	12
Operation	15
Host interface bus	15
Trunk interface unit	26
NT8D14 Universal Trunk Card	29
Introduction	29
Physical description	30
Functional description	33
Card interfaces	34
Card control functions	35
Operation	36
Loop start operation	36
Ground start operation	41
Direct inward dial operation	47
Two-way, loop dial repeating, tie trunk operation	47

Senderized operation for DID and two-way loop DR trunks	54
Outgoing automatic, incoming dial operation	57
Recorded announcement trunk operation	62
Electrical specifications	68
Power requirements	69
Foreign and surge voltage protection	69
Environmental specifications	69
Connector pin assignments	70
Configuration	73
Jumper strap settings	73
Service change entries	73
Applications	81
Paging trunk operation	81
Music operation	82
NT8D15 E&M Trunk Card	83
Introduction	83
Physical description	84
Functional description	86
Card interfaces	87
Trunk interface units	87
Card control functions	92
Maintenance features	94
Operation	94
Signaling and call control	94
Electrical specifications	106
Trunk interface electrical characteristics	106
Power requirements	107
Environmental specifications	107
Foreign and surge voltage protection	107
Connector pin assignments	108
Configuration	111
Jumper settings	111
Software service entries	111

Applications	116
Paging trunk operation	116
QPC71 E&M/DX and Paging Trunk Card	119
Introduction	119
Physical description	119
Functional description	120
Card interfaces	120
Operation	123
Idle circuit states	123
Outgoing calls	124
Incoming calls	130
Transmission	131
Talking connection	131
Paging	132
Trunk signaling conditions	132
Electrical specifications	135
Trunk interface electrical characteristics	135
Overload level	135
Power requirements	136
Foreign and surge voltage protections	136
Environmental specifications	136
Connector pin assignments	137
Configuration	140
Switch settings	140
Service change entries	142
Applications	144
Signaling interface	144
QPC74 Recorded Announcement Trunk Card ...	149
Introduction	149
Physical description	149
Functional description	151
Card interfaces	152

Operation	153
Recorded announcement modes of operation	155
Electrical specifications	158
Trunk interface electrical characteristics	158
Power requirements	159
Foreign and surge voltage protections	159
Environmental specifications	159
Connector pin assignments	160
Configuration	162
Switch settings	162
Software service changes	162
Applications	165
Message recording	165
Multi-language wake-up	166
512-second RAN	167
Recorded announcement machines	168
 QPC237 4-Wire E&M/DX Trunk Card	 173
Introduction	173
Physical description	174
Functional description	176
Card interfaces	176
Operation	181
E&M, Type I signaling	181
E&M, Type II signaling	183
Duplex (DX) signaling	184
Transmission	184
Electrical specifications	195
Trunk interface electrical characteristics	195
Power requirements	196
Foreign and surge voltage protections	196
Environmental specifications	196
Connector pin assignments	197
Configuration	200

Switch settings	200
Service change entries	200
QPC239 Recorded Telephone Dictation Trunk Card with DCK feature	205
Introduction	205
Physical description	206
Functional description	208
Card interfaces	209
Operation	211
Trunk idle	211
Trunk busy	211
Trunk seizure	212
Outpulsing	213
Disconnection	216
Electrical specifications	217
Trunk interface electrical characteristics	217
Overload level	217
Power requirements	218
Foreign and surge voltage protections	218
Environmental specifications	218
Connector pin assignments	219
Configuration	222
Switch settings	222
Service change entries	222
QPC250 Release Link Trunk Card	225
Introduction	225
Physical description	225
Functional description	227
Card interfaces	228
Operation	229
Operation at the remote site	229
Operation at the main site	231

Electrical specifications	233
Trunk interface electrical characteristics	233
Power requirements	234
Foreign and surge voltage protections	234
Environmental specifications	234
Connector pin assignments	235
Configuration	237
Switch and jumper settings	237
Service change entries	237
QPC449 Loop Signaling Trunk Card	239
Introduction	239
Physical description	240
Functional description	242
Card interfaces	243
Operation	244
DID trunk	245
Loop Dial Repeating tie trunk	246
OAID tie trunk	247
Senderized operation for DID and LDR trunks	249
Electrical specifications	250
Trunk interface electrical characteristics	250
Overload level	250
Power requirements	251
Foreign and surge voltage protections	251
Environmental specifications	251
Connector pin assignments	252
Configuration	255
Switch and jumper settings	255
Service change entries	255
QPC450 CO/FX/WATS Trunk Card	259
Introduction	259
Physical description	259

Functional description	261
Card interfaces	262
Trunk interface units	262
Card functions	263
Operation	264
Release control	264
Reverse battery application of metering	264
Periodic metering pulse application of metering	264
Pulse detector	265
PPM interface circuit application	265
Line operation	267
Electrical specifications	274
Trunk interface electrical characteristics	274
Overload level	274
Power requirements	275
Foreign and surge voltage protections	275
Environmental specifications	275
Connector pin assignments	276
Configuration	279
Switch and jumper settings	279
Service change entries	286

List of figures

Figure 1	
Trunk cards in the Meridian 1 architecture	5
Figure 2	
IPE trunk cards installed in an NT8D11 CE/PE Module	12
Figure 3	
IPE trunk cards installed in an NT8D37 IPE Module	13
Figure 4	
PE trunk cards installed in an NT8D13 PE Module	14
Figure 5	
Network connections to PE/IPE modules	17
Figure 6	
Typical IPE trunk card architecture	18
Figure 7	
DS-30X loop data format	21
Figure 8	
Typical PE trunk card architecture	23
Figure 9	
SL-1 Network loop data format	25
Figure 10	
Typical trunk interface unit block diagram	26
Figure 11	
Universal trunk card—faceplate	32
Figure 12	
Universal trunk card—block diagram	33

Figure 13	
Loop start call states—incoming call from CO/FX/WATS	37
Figure 14	
Loop start call connection sequence—incoming call from CO/FX/WATS	38
Figure 15	
Loop start call states—outgoing call to CO/FX/WATS	39
Figure 16	
Loop start call connection sequence—outgoing call to CO/FX/WATS	40
Figure 17	
Ground start call states—incoming call from CO/FX/WATS	42
Figure 18	
Ground start call connection sequence—incoming call from CO/FX/WATS	43
Figure 19	
Ground start call states—outgoing call to CO/FX/WATS	45
Figure 20	
Ground start call connection sequence—outgoing call to CO/FX/WATS	46
Figure 21	
DID trunk, loop DR call states—incoming call from CO	48
Figure 22	
DID trunk, loop DR call connection sequence—incoming call from CO	49
Figure 23	
Two-way, loop DR, tie trunk call states—incoming call from far-end PBX	50
Figure 24	
Two-way, loop DR, tie trunk call connection sequence—incoming call from far-end PBX	51
Figure 25	
Two-way, loop DR, tie trunk call states—outgoing call to far-end PBX	52
Figure 26	
Two-way, loop DR, tie trunk call connection sequence—outgoing call to far-end PBX	53

Figure 27	
Two-way, loop DR, tie trunk call states—incoming call through senderized, tandem PBX from a CO/FX/WATS trunk	55
Figure 28	
Two-way, loop DR, tie trunk call states—outgoing call through far-end PBX to CO/FX/WATS	56
Figure 29	
Two-way, loop OAID, tie trunk call states—incoming call from far-end PBX	58
Figure 30	
Two-way, loop OAID, tie trunk call connection sequence—incoming call from far-end PBX	59
Figure 31	
Two-way, loop OAID, tie trunk call states—outgoing call to far-end PBX	60
Figure 32	
Two-way, loop OAID, tie trunk call connection sequence—outgoing call to far-end PBX	61
Figure 33	
Connecting RAN equipment to the NT8D14 Universal Trunk Card (typical)	63
Figure 34	
RAN control signals (Control GRD = IDLE)	64
Figure 35	
Universal trunk card—typical cross connect example	72
Figure 36	
Universal trunk card—jumper locations (for NT8D14BB release 10 and higher)	76
Figure 37	
Universal trunk card—jumper locations (for NT8D14BA, NT8D14BB release 9 and below)	77
Figure 38	
Connecting paging equipment to the NT8D14 Universal Trunk Card (typical)	81

Figure 39	
E&M trunk card—faceplate	85
Figure 40	
E&M trunk card—block diagram	86
Figure 41	
E&M Type I signaling	89
Figure 42	
E&M Type II signaling	89
Figure 43	
4-wire DX signaling	90
Figure 44	
Paging trunk operation	91
Figure 45	
Signaling orientation for tandem connection between E&M and CO trunks	
95	
Figure 46	
E&M Type I signaling patterns—originating party release	96
Figure 47	
E&M Type I signaling patterns—originating party release on a tandem	
connection	97
Figure 48	
E&M Type II signaling patterns—originating party release	99
Figure 49	
E&M Type II signaling patterns—originating party release on a tandem	
connection	100
Figure 50	
E&M trunk card—typical cross connection example	110
Figure 51	
E&M trunk card—jumper locations	112
Figure 52	
Pad orientation	116
Figure 53	
Paging trunk operation	117

Figure 54	
E&M/DX and paging trunk card—faceplate	121
Figure 55	
E&M/DX and paging trunk card—block diagram	122
Figure 56	
E&M lead signaling patterns, originating party release	128
Figure 57	
E&M lead signaling patterns, originating party release on tandem connections	129
Figure 58	
E&M/DX and paging trunk card—typical cross connection example .	138
Figure 59	
E&M/DX and paging trunk card—switch locations	141
Figure 60	
Pad switching algorithm	143
Figure 61	
Simplified schematic of DX bridge signaling/E&M signaling and paging interface	144
Figure 62	
Simplified schematic of DX bridge signaling circuit	145
Figure 63	
Schematic showing paging system connections	147
Figure 64	
Recorded announcement trunk card—faceplate	150
Figure 65	
Recorded announcement trunk card—block diagram	151
Figure 66	
RAN control signals	156
Figure 67	
Recorded announcement trunk card—typical cross connection example	160
Figure 68	
Recorded announcement trunk card—switch and jumper locations . .	163

Figure 69	
4-wire E&M/DX card—faceplate	175
Figure 70	
4-wire E&M/DX trunk card block diagram	176
Figure 71	
Type I interface	178
Figure 72	
Type II interface	179
Figure 73	
Back-to-back circuit connection	179
Figure 74	
Type I (British Post Office) interface	180
Figure 75	
E&M lead Type I signaling patterns—originating party release (when route does not involve a CO/FX/WATS trunk)	185
Figure 76	
E&M lead Type I signaling patterns—originating party release on tandem connections when originating end is senderized and route is through a CO/ FX/WATS trunk (not applicable to CCSA lines)	186
Figure 77	
E&M lead Type II signaling patterns—originating party release (when route does not involve a CO/FX/WATS trunk)	187
Figure 78	
E&M lead Type II signaling patterns—originating party release on tandem connections when originating end is senderized and route is through a CO/ FX/WATS trunk (not applicable to CCSA lines)	188
Figure 79	
Simplified schematic diagram of a DX signaling (4-wire) circuit for the QPC237A/B	189
Figure 80	
Simplified schematic diagram of a DX signaling (4-wire) circuit for the QPC237C	190

Figure 81	
Simplified schematic diagram of a DX signaling (4-wire) circuit for the QPC237D	191
Figure 82	
4-wire E&M/DX trunk card—typical cross connection example	199
Figure 83	
4-wire E&M trunk card—switch locations	201
Figure 84	
Recorded telephone dictation trunk card—faceplate	207
Figure 85	
Recorded telephone dictation trunk card—block diagram	208
Figure 86	
Out-of-service lead circuit	211
Figure 87	
K1 and K2 relay operation	212
Figure 88	
Seizure and dial pulsing	214
Figure 89	
Talking connection	214
Figure 90	
Answer supervision	215
Figure 91	
Recorded telephone dictation trunk card—typical interconnections ..	221
Figure 92	
Recorded telephone dictation trunk card—switch locations	223
Figure 93	
Release link trunk card—faceplate	226
Figure 94	
Release link trunk card—block diagram	227
Figure 95	
Release link trunk card—typical cross connection example	236

Figure 96	
Release link trunk card—switch and jumper settings	238
Figure 97	
Loop signaling trunk card—faceplate	241
Figure 98	
Loop signaling trunk card—block diagram	242
Figure 99	
Loop signaling trunk card—typical cross connection example	253
Figure 100	
Loop signaling trunk card—switches and jumpers	256
Figure 101	
Pad switching algorithms	257
Figure 102	
CO/FX/WATS trunk card—faceplate	260
Figure 103	
CO/FX/WATS trunk card—block diagram	261
Figure 104	
Metering pulse operation	266
Figure 105	
Ground start trunk incoming call connection sequence	268
Figure 106	
Ground start trunk outgoing call connection sequence	269
Figure 107	
Near end (Meridian 1) disconnects first	270
Figure 108	
Far end (CO) disconnects first	271
Figure 109	
Loop start trunk incoming call connection sequence	272
Figure 110	
Loop start trunk outgoing call connection sequence	273
Figure 111	
CO/FX/WATS trunk card—typical cross connection example	277

Figure 112	
CO/FX/WATS trunk card—switch and jumper settings	280
Figure 113	
Pad switching algorithm	287

List of tables

Table 1	
Trunk card characteristics	8
Table 2	
Differences between PE and IPE modules	16
Table 3	
Trunk and signaling matrix	30
Table 4	
Universal trunk card—trunk interface electrical characteristics	68
Table 5	
Power requirements	69
Table 6	
Environmental specifications	69
Table 7	
Universal trunk card—backplane pinouts	71
Table 8	
Jumper strap settings—factory standard (NT8D14BA, NT8D14BB) .	74
Table 9	
Jumper strap settings—extended range (NT8D14BA, NT8D14BB, NT8D14BB Release 10 and up)	75
Table 10	
Trunk types—termination impedance and balance network (NT8D14BA, NT8D14BB)	78
Table 11	
Cable loop resistance and loss	78

Table 12	
Pad switching algorithm	80
Table 13	
Trunk and signaling matrix	84
Table 14	
Operation mode	98
Table 15	
DX signaling—outgoing calls with originating party release	102
Table 16	
DX signaling—incoming calls with originating party release	103
Table 17	
DX signaling—outgoing calls with originating party release on tandem connections	104
Table 18	
DX signaling—incoming calls with originating party release on tandem connections	105
Table 19	
Electrical characteristics	106
Table 20	
Power requirements	107
Table 21	
Environmental specifications	107
Table 22	
E&M trunk card—backplane pinouts for 2-wire modes	108
Table 23	
E&M trunk card—backplane pinouts for 4-wire modes	109
Table 24	
E&M trunk card—jumper strap settings	113
Table 25	
Pad switching algorithm	115
Table 26	
DX signaling for outgoing calls, originating party release	125

Table 27	
DX signaling for incoming calls, originating party release	126
Table 28	
DX signaling, originating party release on tandem connections, outgoing calls	127
Table 29	
Class of service modes	130
Table 30	
DX signaling, originating party release on tandem connections, incoming calls	134
Table 31	
Trunk interface electrical characteristics	135
Table 32	
Power requirements	136
Table 33	
Environmental specifications	136
Table 34	
E&M/DX and paging trunk card—backplane pinouts	139
Table 35	
E&M/paging trunk card—option switch settings	140
Table 36	
Intercept treatment and associated types of announcements	154
Table 37	
Trunk interface electrical characteristics	158
Table 38	
Recorded announcement trunk card—power requirements	159
Table 39	
Environmental specifications	159
Table 40	
Recorded announcement trunk card—backplane pinouts	161
Table 41	
Recorded announcement trunk card—switch settings for units 0 and 1	164

Table 42	
Recorded announcement trunk card—switch settings for units 2 and 3	164
Table 43	
Start modes	183
Table 44	
DX signaling—originating party release	192
Table 45	
DX signaling—originating party release on tandem connections for outgoing calls	193
Table 46	
DX signaling—originating party release on tandem connections for incoming calls	194
Table 47	
Electrical characteristics	195
Table 48	
Power requirements	196
Table 49	
Environmental specifications	196
Table 50	
4-wire E&M/DX trunk card—connections	198
Table 51	
4-wire E&M trunk card—S1 and S2 switch settings	202
Table 52	
4-wire E&M trunk card—S3, S4, S5, and S6 switch settings	203
Table 53	
Connections to recording machines	210
Table 54	
Trunk interface electrical characteristics	217
Table 55	
Power requirements	218
Table 56	
Environmental specifications	218

Table 57	
Recorded telephone dictation trunk card—connections	220
Table 58	
Recorded telephone dictation trunk card—switch settings	222
Table 59	
Electrical specifications	233
Table 60	
Power requirements	234
Table 61	
Environmental specifications	234
Table 62	
Release link trunk card—backplane pinouts	235
Table 63	
Application and compatibilities	244
Table 64	
Electrical characteristics	250
Table 65	
Power requirements	251
Table 66	
Environmental specifications	251
Table 67	
Loop signaling trunk card—backplane pinouts	254
Table 68	
Trunk characteristics	274
Table 69	
Power requirements	275
Table 70	
Environmental specifications	275
Table 71	
CO/FX/WATS trunk card—backplane pinouts	278

Table 72	
QPC450A&B vintage CO/FX/WATS trunk card—switch and jumper settings	281
Table 73	
QPC450C CO/FX/WATS trunk card—switch settings	282
Table 74	
QPC450C1 & D CO/FX/WATS trunk card—switch settings	283
Table 75	
QPC450 E&F trunk cards—switch settings	284
Table 76	
QPC450G CO/FX/WATS trunk card—switch settings	285